




CrystalSound
radio equipment for excursions

Instruction DCS-210




THE TRANSMITTER



1. Synchronization
2. Mute
3. Microphone connector
4. Battery charge level indicator
5. Mute indicator / built-in microphone
6. Charger connector
7. Built-in microphone

THE RECEIVER



1. Volume up
2. Volume down
3. Earphone connector
4. Battery charge level indicator
5. Signal strength indicator
6. Charger connector



During synchronization, one of the 775 channels is automatically selected. To save battery, it is recommended to disconnect equipment in the end of the tour

SYNCHRONIZATION

Performed when the earphones / microphone are disconnected



Holding button  bring the transmitter to the receiver



When Synchronization is successful, the backlight turns on

TO SWITCH ON / SWITCH OFF



To switch on the device, connect the earphone / microphone to the receiver / transmitter



To switch off the device, remove earphone / microphone



If there no signal from the transmitter for more than 3 minutes, the receiver will be automatically switched off

THE SIGNAL LEVEL



There is signal



The connection was lost

BATTERY CHARGE



Connect the charge to the device. When the device is fully charged the green LED will be lit up



To charge several devices at the same time, use special equipment



To be fully charged from 0 to 100% it will take 2.5 hours. The operating time of the transmitter is 60 hours, the receiver 100 hours

MICROPHONE MUTE



To switch off

Hold the button 
for 1-2 seconds until red
LED is lit up



To switch on

Hold the button 
for 1-2 seconds until red
LED is turned off

BUILT-IN MICROPHONE



To switch on

Hold on buttons 
at the same moment 
for 3-5 sec until the green
LED is lit up



To switch off

Hold on buttons 
at the same moment 
for 3-5 sec until the green
LED is turned off



The transmitter is able to work without
connecting an external microphone



the_crystal_sound



thecrystalsound2014



thecrystalsound

Saint-Petersburg +7 812 300 05 15 (techsupport)
+7 812 608 50 15 (head office Russia)
hello@crystal-sound.com

Moscow +7 925 235 47 05
hello@crystal-sound.com

Barcelona +34 932 202 706
spain@crystal-sound.com

Riga +371 665 55 007
latvia@crystal-sound.com

Roma +39 366 358 62 74
italy@crystal-sound.com

Tallinn +372 880 13 74
estonia@crystal-sound.com

Vilnius +370 521 408 77
lithuania@crystal-sound.com